

# INSTALLATION INSTRUCTIONS

DLZ Creator Firmware Update • May 2023

## Introduction

These installation instructions describe how to update the DLZ Creator firmware with the latest version.

## System Requirements

- Windows 10 or higher required
- macOS 10.12 or higher required

## Supported Devices

- DLZ Creator

## Installation Instructions for macOS

1. Place a flash drive or microSD Card into the correct slot of the computer. It will appear on the desktop.

2. Download the latest DLZ Creator Firmware Update .zip file from the Mackie website.

3. Navigate to the location where the file was downloaded. This will most likely be in the Downloads folder, but could be the desktop (or elsewhere).

4. Find the file named “evolveupdate-b1219-20230318.zip” (or similar) then double-click to unzip.

5. Confirm that the unzipped file named “evolveupdate-b1219-20230318.upd” (or similar) is at the top/root level and not buried in a folder or sub-folder.

6. Drag the unzipped “evolveupdate-b1219-20230318.upd” (or similar) file to the top/root level of the flash drive or microSD Card.

7. Right-click on the flash drive or microSD Card and select ‘Eject’.

8. Place the flash drive or microSD Card into the correct slot of the DLZ Creator and power up DLZ Creator.

9. Now the file has to “play” in order for it to install. Do so by navigating to the Media tab and selecting either ‘usb:\’ or ‘sd:\’, depending on where you placed the file, of course! It will be highlighted to indicate that it has been selected.

10. Near the upper-left corner – underneath the Channel tab – is a hand with the index finger pointing up. Tap it so the files on the selected source are visible.

11. Search for the file named “evolveupdate-b1219-20230318.upd” (or similar) and tap it so it illuminates, indicating that it is selected.

12. Tap the hand with the index finger icon again in order to “play” the file. This is a permanent deletion with no undo, so a confirmation dialog helps prevent accidents.

13. Please be patient! Do not unplug or power off the mixer while the update is being installed. A popover will indicate success when completed.

14. Now go make some podcasts!

# Installation Instructions for Windows

1. Place a flash drive or microSD Card into the correct slot of the computer. It will appear on the desktop.

2. Download the latest DLZ Creator Firmware Update .zip file from the Mackie website.

3. Navigate to the location where the file was downloaded. This will most likely be in the Downloads folder, but could be the desktop (or elsewhere).

4. Find the file named “evolveupdate-b1219-20230318.zip” (or similar) then right-click and select ‘extract all’. Accept all prompts by clicking ‘OK’ and/or ‘Next’.

5. Confirm that the unzipped file named “evolveupdate-b1219-20230318.upd” (or similar) is at the top/root level and not buried in a folder or sub-folder.

6. Drag the extracted “evolveupdate-b1219-20230318.upd” (or similar) file to the top/root level of the flash drive or microSD Card.

7. Right-click on the flash drive or microSD Card and select ‘Eject’.

8. Place the flash drive or microSD Card into the correct slot of the DLZ Creator and power up DLZ Creator.

9. Now the file has to “play” in order for it to install. Do so by navigating to the Media tab and selecting either ‘usb:\’ or ‘sd:\’, depending on where you placed the file, of course! It will be highlighted to indicate that it has been selected.

10. Near the upper-left corner – underneath the Channel tab – is a hand with the index finger pointing up. Tap it so the files on the selected source are visible.

11. Search for the file named “evolveupdate-b1219-20230318.upd” (or similar) and tap it so it illuminates, indicating that it is selected.

12. Tap the hand with the index finger icon again in order to “play” the file. This is a permanent deletion with no undo, so a confirmation dialog helps prevent accidents.

13. Please be patient! Do not unplug or power off the mixer while the update is being installed. A popover will indicate success when completed.

14. Now go make some podcasts!

## Technical Support

Please contact our splendid Technical Support heroes if you have any questions.

Web: <http://www.mackie.com/support>

Phone: 800-898-3211  
425-487-4333

During normal business hours, Monday-Friday, Pacific Time.